

# ASSEMBLY & OPERATING INSTRUCTIONS

## MOTORIZED SHOE CLEANER


MODEL # 1600

### INTRODUCTION

MODEL	DESCRIPTION
1600VA-H	Fully automatic shoe cleaner with hepa filter - providing advanced filtration, quieter operation, built in vacuum, and disposable dust bags.
1600VA	Fully automatic shoe cleaner with built in vacuum pump and disposable dust bags.
1600SA	Fully automatic shoe cleaner for use with external vacuum systems.


### SPECIFICATION

Size of Main Unit	18" W x 27" L x 10.5" H
Overall Height With Handle	40"
Weight	47 LBS
Shipping Weight	55 LBS
Voltage	110-120V AC
Cycle	60 CYL
Amperage - No Load	8 AMPS
Amperage - Under Load	12 AMPS
Electrical Connection	Extension cord with parallel blades and "U" shaped ground connector for wall outlet
Vacuum Exhaust	1.50 I.D. x 1.75 O.D.
Design	<ul style="list-style-type: none"> <li>- Rugged design gives long life</li> <li>- Large footprint for stability</li> <li>- Simple to operate</li> <li>- 5 brushes for complete contamination removal</li> <li>- Speed control, brush motor</li> </ul>



## ASSEMBLY

INSERT HANDLE INTO MATING SOCKETS IN SHOE BRUSHER. FOR PROPER INSTALLATION, THE HANDLE SHOULD BE INSERTED THE FULL DEPTH OF THE STUBS



- TO OPERATE THE MOTORIZED SHOE CLEANER, PUSH THE HANDLE SLOWLY TO THE REAR WHILE MOVING YOUR SHOE FLAT IN A FORWARD MOTION BETWEEN ROTATING BRUSHES.